

PROGRAM PR2_Leak_Detection

VAR

// --- Hardware Inputs (Mapped to Beckhoff ELM3148) ---

iRawAnalogInput AT %I* : INT; // Raw 4-20mA input from DLS panel

bStartTestCycle : BOOL; // Triggered by FAT rig operator to begin leak test

// --- System Configuration Constants (1kg Top-Down Architecture) ---

c_iRawMin : INT := 0; // Raw integer value at 4mA (Beckhoff specific, often 0)

c_iRawMax : INT := 32767; // Raw integer value at 20mA (Beckhoff specific 16-bit)

c_rSensorCapacity : REAL := 1000.0; // 1kg load cell (in grams)

c_tSettleTime : TIME := T#3S; // 3-second mechanical deadband for suspension swing

// --- Internal Logic Variables ---

rAbsoluteMass : REAL; // Total mass currently hanging on the sensor

rTareMass : REAL; // The captured weight of the empty bottle (approx 54g)

bTareComplete : BOOL; // Flag indicating system is zeroed and ready

rActiveLeakMass : REAL; // The calculated leak volume

// --- Function Blocks ---

fbSettleTimer : TON; // Timer for the deadband

fbTareTrigger : R_TRIG; // Rising edge trigger to capture tare once

END_VAR

// =====

// 1. Analog Input Scaling (4-20mA to Grams)

// =====

// Convert the raw Beckhoff integer into a percentage, then multiply by the 1000g capacity.

IF c_iRawMax > c_iRawMin THEN

 rAbsoluteMass := (INT_TO_REAL(iRawAnalogInput - c_iRawMin) / INT_TO_REAL(c_iRawMax - c_iRawMin)) * c_rSensorCapacity;

ELSE

 rAbsoluteMass := 0.0; // Prevent divide by zero error

END_IF

// =====

// 2. Mechanical Deadband & Tare Logic

// =====

// Start the settling timer only when the operator begins the test cycle.

fbSettleTimer(IN := bStartTestCycle, PT := c_tSettleTime);

// When the timer finishes, trigger the tare capture ONCE.

fbTareTrigger(CLK := fbSettleTimer.Q);

// Execute the Tare: Store the absolute mass into the memory variable.

IF fbTareTrigger.Q THEN

 rTareMass := rAbsoluteMass;

 bTareComplete := TRUE;

END_IF

// Reset logic if test is stopped

IF NOT bStartTestCycle THEN

 bTareComplete := FALSE;

 rTareMass := 0.0;

```

    rActiveLeakMass := 0.0;
END_IF

// =====
// 3. Active Leak Measurement (1g = 1ml)
// =====
// Only calculate the leak if the system has successfully tared the 54g bottle.
IF bTareComplete THEN
    // Active leak is current mass minus the stored tare mass.
    rActiveLeakMass := rAbsoluteMass - rTareMass;

    // Optional: Implement a software filter to prevent negative readings from ambient vibration
    IF rActiveLeakMass < 0.0 THEN
        rActiveLeakMass := 0.0;
    END_IF
ELSE
    rActiveLeakMass := 0.0; // Output is zero while stabilizing
END_IF

// Note: rActiveLeakMass now directly represents milliliters of leaked fluid (PR2 data).

```